

How to Find Your ATV or UTV Tire Size

Your tire size is usually molded into the sidewall of the tire already on your machine.

Example sidewall marking

27

Overall diameter

x

9

Section width

R

Radial

12

Rim diameter

Where to look

1. Tire sidewall
2. Tire-information label or owner's manual
3. Whips Garage Shop by Machine fitment

Check front AND rear

Many ATVs and UTVs use a narrower front tire and a wider rear tire. Check both ends before ordering a complete set.

Example: Front 27x9R12 Rear 27x11R12

Do not assume the tires on the machine are factory size.

Previous owners may have installed a different size. If you are replacing what is on the machine now, use the size printed on those tires. For original equipment size, check the manufacturer information or ask us.

Use the printed size - not just a tape measure

The numbers in a tire size are nominal. Actual mounted dimensions can vary by tire model, construction, rim width, pressure, and load. Use the molded sidewall size whenever possible.

Still not sure?

Send Whips Garage a clear photo of the tire-size marking on your front and rear tires and we can help identify what you need.